



1	Agitator shaft	16	Gear	31	Handle seat	46	VAT clamp	61	Button switch
2	Agitator shaft sleeving	17	Shaft sleeving	32	Eccentric sleeve	47	carriage	62	Switch mounting plate
3	Planetary gear	18	Gear	33	Front cover	48	Nut	63	Electrical box
4	spacer	19	sleeve	34	front	49	body	64	Overload protector
5	Pressure spring	20	Gear shaft	35	Self lock nut	50	Jiggle bar	65	Capacitance
6	Clutch body	21	Bevel gear	36	Front housing	51	Connecti on pad	66	A.C Contactor
7	47-gear	22	Back cover	37	Spring	52	Spring	67	Power cord
8	46-bevel gear wheel	23	Back housing	38	Bevel gear	53	Joint level	68	Left and right guard plate

9	29-small gear	24	Motor rotor	39	Sleeve	54	Connecti on rotate seat	69	meat grind er, (HL-B20M only)
10	Sleeve	25	Worm gear sleeve	40	Inner gear	55	Mix level		
11	Mesh gear	26	Worm gear	41	Mixing seat	56	mixer		
12	Upper cover	27	Body	42	Mixing seat	57	agitator		
13	Transmissio n shaft upper cover	28	Shifting block shaft	43	Planetary gear	58	Activiti es cover		
14	Bearing bottom cover	29	Shifting block	44	Transmiss ion shaft	59	tank		
15	gear	30	Shifting handle	45	Bottom seat	60	Fixed protecti on cover		